

材质: 300G双粉+双面印刷+过哑胶

颜色: C M Y K

尺寸: 787.5 mm x 210 mm

SIZE: 787.5 mm x 210 mm



For immediate help with assembly, product information, or to order replacement parts, call: 1-888-919-0070, email: warranty@polygroup.com

Renseignements, assemblage et pièces: 1-888-919 0070 ou warranty@polygroup.com

Para asistencia con el ensamble, partes y servicio al cliente, llame al: 1-888-919-0070, correo electrónico: warranty@polygroup.com

SHAPING YOUR GROW & STOW™ TREE FORME

COMO DAR FORMA AL ARBOL GROW & STOW™ Your Grow & Stow™ Tree is built and designed with Simple Shape™ Memory Wire tips that are already pre-shaped at the factory.

Le bout des branches de l'arbre Grow & Stow™ est fait de fil métallique à mémoire Simple Shape™ préformé en usine.

Su árbol Grow & Stow™ está construido y diseñado con alambre Simple Shape™ de puntas con memoria que ya vienen conformadas de fábrica.

STORING YOUR GROW & STOW™ TREE RANGEMENT

GUARDAR SU ARBOL GROW & STOW™

1. PLACE SAFETY LOCK SWITCH ON UNLOCK POSITION PLACER L'INTERRUPTEUR DE VERROUILLAGE EN POSITION DE DÉVERROUILLAGE

2. USE EITHER REMOTE CONTROL OR FOOT PEDAL TO ACTIVATE THE STOW FUNCTION

UTILISER LA TÉLÉCOMMANDE OU LE LEVIER DE COMMANDE À PIED POUR FAIRE DÉCROÎTRE L'ARBRE

UTILICE EL CONTROL REMOTO O EL PEDAL PARA ACTIVAR LA FUNCIÓN DE CERRAR

Please make sure to remove all ornaments and decorations prior to using stow function.

UNPLUG THE TREE AND PLACE ALL ACCESSORIES INTO PARTS BAG

DEBRANCHER L'ARBRE ET PLACER TOUS LES ACCESSOIRES DANS LE SAC DE PIÈCES

DESCONECTE EL ARBOL Y COLOQUE TODOS LOS ACCESORIOS EN LAS BOLSAS DE LAS PARTES

REMOVE TREE TOP AND PLACE IN TREE TOP BAG

RETIRE LE HAUT DE L'ARBRE ET LE PLACER DANS LE SAC

QUITE LA PARTE SUPERIOR DEL ARBOL Y COLOQUELA EN LA BOLSA DE LA PARTE SUPERIOR DEL ARBOL

7

5. CLOSE PROTECTIVE CAP OVER TREE BASE POLE

FERMER LE CAPUCHON PROTECTEUR AU SOMMET DE LA BASE

CIERRE LA TAPA DE PROTECCIÓN SOBRE EL POSTE DE LA BASE DEL ÁRBOL



6. PULL STORAGE BAG OVER TREE BASE

GLISSER LE SAC DE RANGEMENT PAR-DESSUS LA BASE DE L'ARBRE

EMPUJE LA BOLSA DE ALMACENAMIENTO SOBRE LA BASE DEL ÁRBOL



7. CINCH AND TIGHTEN DRAW STRINGS AND BUCKLE STRAPS

SERRER LES CORDONS ET ATTACHER LA SANGLE

ENCINTE Y APRIETE LOS CORDONES DE LAS JARETAS Y LAS CORREAS DE AJUSTE

UNLOCK WHEELS BEFORE STORING / DÉVERROUILLER LES ROUES AVANT LE RANGEMENT /

DESTRABE LAS RUEDAS ANTES DE GUARDAR

9. STORE IN COOL, DRY AREA WAY FROM SUNLIGHT

RANGER DANS UN ENDROIT FRAIS ET SEC À L'ABRI DU SOLEIL

GUARDE EN UN LUGAR FRESCO Y SECO, LEJOS DE LA LUZ DEL SOL

Exposing your tree to excessive heat or humidity may damage your tree.

Exponer su árbol a calor o humedad excesivos puede dañar su árbol.

8

TROUBLESHOOTING / DÉPANNAGE / SOLUCIÓN DE PROBLEMAS

THE TREE LIGHTS DO NOT ILLUMINATE LES LUMIÈRES NE S'ALLUMENT PAS

LAS LUCES DEL ÁRBOL NO SE ENCENDEN

Ensure that the power cord is plugged into a wall outlet.

Check the remote for batteries and then try switching the remote off and on.

Press the light button on the foot pedal.

If the tree top does not light up, check that the Quick Set™ tree top is securely set into the tree base.

If a section does not illuminate, unplug the power cord and check that section for loose or missing bulbs.

Tree Life Cycle: 3000 Cycles Max.

Remote Controller Range: 33 ft (10 m)

Remote Controller Power: DC 3V

Operational Temperature: 0°C to 40°C

Storage Temperature: -5°C to 60°C

THE GROW AND STOW FUNCTIONS DO NOT WORK

Check to make sure all wires are connected properly following setup instructions.

9

Check lock switch on the foot pedal. Switch it to "UNLOCK" position.

THE TREE DOES NOT LOOK STRAIGHT

Check to make sure the floor is level and that all four wheels are on the same surface.

PRODUCT SPECIFICATIONS

Table with 2 columns: Feature and Specification. Includes details for power supply, tree range, life cycle, remote control, and storage conditions.

10



ASSEMBLY AND CARE INSTRUCTIONS



Congratulations on purchasing your new Grow & Stow™ Tree from Polygroup™

SIZE: 787.5 mm x 210 mm

GROW & STOW™ AT A GLANCE

PARTIES DE L'ARBRE GROW & STOW™

GROW & STOW™ A SIMPLE VISTA



GROW & STOW™ INCLUDED ACCESSORIES

ACCESORIOS INCLUIDOS

ACCESORIOS INCLUIDOS GROW & STOW™



1

SETTING UP YOUR GROW & STOW™ TREE

ASSEMBLAGE

ENSEMBLE DE SU ARBOL GROW & STOW™

Please review these instructions carefully to help you set up your tree.

1. REMOVE ALL PARTS FROM THE BOX

2. WHEEL TREE BASE TO SET LOCATION

3. REMOVE TREE PARTS FROM STORAGE BAG

4. LOCK WHEELS ON TREE STAND

5. OPEN PROTECTIVE CAP AT POLE CONNECTION

6. ASSEMBLE TREE BY INSERTING THE TREE TOP INTO TREE BASE

7. CONNECT WIRES INTO FOOT PEDAL AND POWER ADAPTOR

8. LOCK WHEELS ON TREE STAND

9. STORE IN COOL, DRY AREA WAY FROM SUNLIGHT

10. UNLOCK WHEELS BEFORE STORING

11. REMOVE TREE TOP AND PLACE IN TREE TOP BAG

12. STORE IN COOL, DRY AREA WAY FROM SUNLIGHT

2

5. OPEN PROTECTIVE CAP AT POLE CONNECTION

6. ASSEMBLE TREE BY INSERTING THE TREE TOP INTO TREE BASE

7. CONNECT WIRES INTO FOOT PEDAL AND POWER ADAPTOR

8. LOCK WHEELS ON TREE STAND

9. STORE IN COOL, DRY AREA WAY FROM SUNLIGHT

10. UNLOCK WHEELS BEFORE STORING

11. REMOVE TREE TOP AND PLACE IN TREE TOP BAG

12. STORE IN COOL, DRY AREA WAY FROM SUNLIGHT

13. REMOVE TREE TOP AND PLACE IN TREE TOP BAG

14. STORE IN COOL, DRY AREA WAY FROM SUNLIGHT

15. REMOVE TREE TOP AND PLACE IN TREE TOP BAG

16. STORE IN COOL, DRY AREA WAY FROM SUNLIGHT

17. REMOVE TREE TOP AND PLACE IN TREE TOP BAG

18. STORE IN COOL, DRY AREA WAY FROM SUNLIGHT

19. REMOVE TREE TOP AND PLACE IN TREE TOP BAG

20. STORE IN COOL, DRY AREA WAY FROM SUNLIGHT

3

OPERATING YOUR GROW & STOW™ TREE

UTILISATION DE L'ARBRE GROW & STOW™

OPERAR SU ARBOL GROW & STOW™

Your Grow & Stow™ Tree can be operated using either the included foot pedal or remote control.

FOOT PEDAL OPERATION

1. PLACE SAFETY LOCK SWITCH TO UNLOCK POSITION

2. PRESS THE TREE LOGO BUTTON TO START GROW FUNCTION

3. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

4. PRESS THE UP BUTTON TO START GROW FUNCTION

5. PRESS THE DOWN BUTTON TO START STOW FUNCTION

6. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

7. PRESS THE UP BUTTON TO START GROW FUNCTION

8. PRESS THE DOWN BUTTON TO START STOW FUNCTION

9. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

10. PRESS THE UP BUTTON TO START GROW FUNCTION

11. PRESS THE DOWN BUTTON TO START STOW FUNCTION

4

Press this button at any time to control height and toggle between Grow, Pause, or Stow function.

3. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

4. PRESS THE UP BUTTON TO START GROW FUNCTION

5. PRESS THE DOWN BUTTON TO START STOW FUNCTION

6. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

7. PRESS THE UP BUTTON TO START GROW FUNCTION

8. PRESS THE DOWN BUTTON TO START STOW FUNCTION

9. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

10. PRESS THE UP BUTTON TO START GROW FUNCTION

11. PRESS THE DOWN BUTTON TO START STOW FUNCTION

12. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

13. PRESS THE UP BUTTON TO START GROW FUNCTION

14. PRESS THE DOWN BUTTON TO START STOW FUNCTION

15. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

16. PRESS THE UP BUTTON TO START GROW FUNCTION

17. PRESS THE DOWN BUTTON TO START STOW FUNCTION

5

INSERT TWO AAA BATTERIES (NOT INCLUDED) INTO BATTERY COMPARTMENT

2. PRESS THE UP BUTTON TO START GROW FUNCTION

3. PRESS THE DOWN BUTTON TO START STOW FUNCTION

4. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

5. IMPORTANT: PLACE SAFETY LOCK SWITCH TO LOCK POSITION

6. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

7. PRESS THE UP BUTTON TO START GROW FUNCTION

8. PRESS THE DOWN BUTTON TO START STOW FUNCTION

9. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

10. PRESS THE UP BUTTON TO START GROW FUNCTION

11. PRESS THE DOWN BUTTON TO START STOW FUNCTION

12. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

13. PRESS THE UP BUTTON TO START GROW FUNCTION

14. PRESS THE DOWN BUTTON TO START STOW FUNCTION

15. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS

16. PRESS THE UP BUTTON TO START GROW FUNCTION

17. PRESS THE DOWN BUTTON TO START STOW FUNCTION

6