


# Assembly Instructions


1. Insert tree body into the weighted pot.



2. Insert the tree top into the trunk of the main body. (as shown in fig.1)



3. Shape the branches. Shift branches to fill any gaps, lightly upsweep all branch tips for a uniform look. Your tree is now ready to decorate.



4. Plug the cord into wall outlet.

## STORAGE:


- (1) Unplug light string from the wall outlet and remove all ornaments and decorations.
- (2) Gently lift off the top, and remove the bottom section from the tree pot.
- (3) Carefully replace the tree in its box and tape it shut.

DO NOT STORE TREE IN A DAMP AREA OR IN AN AREA WHERE THE TEMPERATURE EXCEEDS 100° F.


MODEL#: TV46M4F18C02

# Instructions De Montage

1. Insérez le corps de l'arbre dans le pot avec poids




2. Insérez le haut de l'arbre dans le tronc du corps principal. (Voir Fig.1)



3. Donnez forme aux branches. Jouez avec celles-ci afin de réduire les espaces apparents. Nettoyez tous les embouts des branches pour donner un aspect plus uniforme. Votre arbre est maintenant prêt à décorer.

4. Branchez le fil dans la prise murale.



## RANGEMENT:

- (1) Débrancher la guirlande de lumières de la prise de courant et retirer toutes les décorations.
- (2) Soulever délicatement le dessus et retirer la section inférieure du contenant de l'arbre.
- (3) Remettre soigneusement l'arbre dans la boîte et la sceller avec du ruban gommant.  
N'ENTREPOSEZ PAS L'ARBRE DANS UN ENDROIT HUMIDE OU DANS UN ENDROIT OÙ LA TEMPÉRATURE EXCÈDE 100° F.