

4' LIGHTED JACKSON POTTED TREE

model no. 151-6341-2 | Toll-free number: 1-866-827-4985


IMPORTANT: Please read this manual carefully before assembly and save it for reference

TREE ASSEMBLY INSTRUCTIONS

Carefully follow the instructions below to quickly and easily set up your new tree.

1. Before you start to assemble your tree, choose an appropriate location near a wall outlet.
2. Place the tree pot on a level surface.
3. Insert the tree body into the tree pot, and then insert the tree top into the trunk of the main body (as shown in **Fig. 1**).
4. Shape the branches. Shift branches to fill any gaps. Upsweep all branch tips for a uniform look. Your tree is now ready to decorate. Plug the cord into wall outlet.
5. When multiple products are connected together, do not exceed the lowest of the indicated maximum wattage on the cord tag near the connected product's receptacle.

Fig. 1



This product carries a one (1) year warranty against defects in workmanship and materials. Noma Canada agrees to replace a defective product, within the stated warranty period, when returned to the place of purchase with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

STORAGE:

1. Unplug adaptor from the wall outlet first and then remove all ornaments and decorations.
2. Gently lift off the tree body from the tree pot.
3. Carefully place the tree in its box and tape it shut. DO NOT STORE TREE IN A DAMP AREA OR IN AN AREA WHERE THE TEMPERATURE EXCEEDS 100°F (38°C).

Warranty

Made in China
Imported by
Noma Canada, Toronto, Canada M4S 2B8

DATE CODE / DATE DE CODE: 22318