

材质: 300G双粉+双面印刷+过哑胶

颜色: C M Y K

尺寸: 787.5 mm x 210 mm

SIZE: 787.5 mm x 210 mm



For immediate help with assembly, product information, or to order replacement parts, call: 1-888-919-0070, email: warranty@polygroup.com

Renseignements, assemblage et pièces: 1-888-919 0070 ou warranty@polygroup.com

Para asistencia con el ensamble, partes y servicio al cliente, llame al: 1-888-919-0070, correo electrónico: warranty@polygroup.com

SHAPING YOUR GROW & STOW™ TREE FORME

COMO DAR FORMA AL ARBOL GROW & STOW™ Your Grow & Stow™ Tree is built and designed with Simple Shape™ Memory Wire tips that are already pre-shaped at the factory.

Le bout des branches de l'arbre Grow & Stow™ est fait de fil métallique à mémoire Simple Shape™ préformé en usine.

Su árbol Grow & Stow™ está construido y diseñado con alambre Simple Shape™ de puntas con memoria que ya vienen conformadas de fábrica.

STORING YOUR GROW & STOW™ TREE RANGEMENT

GUARDAR SU ARBOL GROW & STOW™ 1. PLACE SAFETY LOCK SWITCH ON UNLOCK POSITION

2. USE EITHER REMOTE CONTROL OR FOOT PEDAL TO ACTIVATE THE STOW FUNCTION

3. UNPLUG THE TREE AND PLACE ALL ACCESSORIES INTO PARTS BAG

4. REMOVE TREE TOP AND PLACE IN TREE TOP BAG



7

5. CLOSE PROTECTIVE CAP OVER TREE BASE PILE



6. PULL STORAGE BAG OVER TREE BASE



7. CINCH AND TIGHTEN DRAW STRINGS AND BUCKLE STRAPS



8. UNLOCK WHEELS BEFORE STORING / DÉVERROUILLER LES ROUES AVANT LE RANGEMENT

9. STORE IN COOL, DRY AREA WAY FROM SUNLIGHT

Exposing your tree to excessive heat or humidity may damage your tree.

8

TROUBLESHOOTING / DÉPANNAGE / SOLUCIÓN DE PROBLEMAS

THE TREE LIGHTS DO NOT ILLUMINATE

• Ensure that the power cord is plugged into a wall outlet. If the tree is plugged into a switch controlled wall outlet, make sure the switch is turned on.

• Check the remote for batteries and then try switching the remote off and on.

• Press the light button on the foot pedal.

• If the tree top does not light up, check that the Quick Set™ tree top is securely set into the tree base.

• If a section does not illuminate, unplug the power cord and check that section for loose or missing bulbs.

• Tree Life Cycle: 3000 Cycles Max.

• Remote Controller Range: 33 ft (10 m)

• Remote Controller Power: DC 3V

• Operational Temperature: 0°C to 40°C

• Storage Temperature: -5°C to 60°C

9

• Check lock switch on the foot pedal. Switch it to "UNLOCK" position.

• The TREE DOES NOT LOOK STRAIGHT

• Check to make sure the floor is level and that all four wheels are on the same surface.

PRODUCT SPECIFICATIONS

Table with 2 columns: Feature and Specification. Includes details for power supply, tree range, stroke, life cycle, remote control, and storage conditions.

10



ASSEMBLY AND CARE INSTRUCTIONS



Congratulations on purchasing your new Grow & Stow™ Tree from Polygroup™

SIZE: 787.5 mm x 210 mm

GROW & STOW™ AT A GLANCE

Parties de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

Partes de l'arbre Grow & Stow™

SETTING UP YOUR GROW & STOW™ TREE

ASSEMBLAGE ENSEMBLE DE SU ARBOL GROW & STOW™

1. REMOVE ALL PARTS FROM THE BOX

2. WHEEL TREE BASE TO SET LOCATION


3. REMOVE TREE PARTS FROM STORAGE BAG

4. LOCK WHEELS ON TREE STAND



2


5. OPEN PROTECTIVE CAP AT POLE CONNECTION



6. ASSEMBLE TREE BY INSERTING THE TREE TOP INTO TREE BASE

7. CONNECT WIRES INTO FOOT PEDAL AND POWER ADAPTOR

8. FOLLOW CORRESPONDING PIN CONNECTORS TO CONNECT TREE TO FOOT PEDAL



3



OPERATING YOUR GROW & STOW™ TREE

UTILISATION DE L'ARBRE GROW & STOW™

OPERAR SU ARBOL GROW & STOW™

FOOT PEDAL OPERATION

UTILISATION DU LEVIER DE COMMANDE À PIED

OPERACION DEL PEDAL

1. PLACE SAFETY LOCK SWITCH TO UNLOCK POSITION

2. PRESS THE TREE LOGO BUTTON TO START GROW FUNCTION

3. PRESS THE UP BUTTON TO START GROW FUNCTION

4. PRESS THE DOWN BUTTON TO START STOW FUNCTION

4

• Press this button at any time to control height and toggle between Grow, Pause, or Stow function.

3. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS AND TO CONTROL LIGHT STRING EFFECTS

4. IMPORTANT: PLACE SAFETY LOCK SWITCH TO LOCK POSITION

• When in lock position, both the foot pedal and remote control will not be able to Grow or Stow the tree.

REMOTE CONTROL OPERATION / UTILISATION DE LA TÉLÉCOMMANDE / OPERACION DEL CONTROL REMOTO

Remote LED Indicator

Remote Light Functions Button

Remote Battery Compartment and Lid

Grow (Up and Pause) Button

Stow (Down and Pause) Button

• To prevent accidental stowing of your tree when fully decorated.

• When in lock position, both the foot pedal and remote control will not be able to Grow or Stow the tree.

• When in lock position, both the foot pedal and remote control will not be able to Grow or Stow the tree.

• When in lock position, both the foot pedal and remote control will not be able to Grow or Stow the tree.

5

1. INSERT TWO AAA BATTERIES (NOT INCLUDED) INTO BATTERY COMPARTMENT

2. PRESS THE UP BUTTON TO START GROW FUNCTION

3. PRESS THE DOWN BUTTON TO START STOW FUNCTION

4. PRESS THE LIGHT BUTTON TO TURN ON/OFF YOUR LIGHTS AND TO CONTROL LIGHT STRING EFFECTS

5. IMPORTANT: PLACE SAFETY LOCK SWITCH TO LOCK POSITION

• To prevent accidental stowing of your tree when fully decorated.

• When in lock position, both the foot pedal and remote control will not be able to Grow or Stow the tree.

• When in lock position, both the foot pedal and remote control will not be able to Grow or Stow the tree.

• When in lock position, both the foot pedal and remote control will not be able to Grow or Stow the tree.

• When in lock position, both the foot pedal and remote control will not be able to Grow or Stow the tree.

• When in lock position, both the foot pedal and remote control will not be able to Grow or Stow the tree.

• When in lock position, both the foot pedal and remote control will not be able to Grow or Stow the tree.

• When in lock position, both the foot pedal and remote control will not be able to Grow or Stow the tree.

• When in lock position, both the foot pedal and remote control will not be able to Grow or Stow the tree.

6