

## INSERTING THE BATTERIES

1. Locate battery compartment on the product.
2. Remove compartment cover by unscrewing it with a screwdriver.
3. Insert 3 pcs AA battery as indicated in diagram below. Fig. 1  
Make sure the batteries are inserted in the correct direction and polarity.
4. Replace compartment cover, re-insert screws & tighten.  
If the lights did not turn ON, press the ON/OFF button.
5. BATTERIES ARE NOT INCLUDED.
6. DISPOSE OF USED BATTERIES PER MUNICIPAL OR PROVINCIAL LAW.

FIG. 1




FIG. 2




FIG. 1





FIG. 2



## TIMER OPERATING INSTRUCTIONS

This battery operated control box comes with a pre-set timer function.

1. When you press ON (Fig 2), the lights will automatically come on and stay lit for 6 hours.
2. The lights will automatically turn off after the 6 hours and remain off for 18 hours. This cycle will then continue until you press off.

## WARNING

1. Do not mix alkaline, standard (Carbon - Zinc), lithium, or rechargeable (NiCd, NiMH or other type) batteries
2. Remove batteries when not used for an extended period of time, or when depleted.
3. Dispose of used batteries properly by following directions on batteries.
4. Clean the battery contacts prior to battery installation.
5. Caution - when replacing the batteries, you must only replace with AA type batteries.
6. Do not mix old and new batteries (or different types of batteries).
7. Indoor / Outdoor use.
8. WARNING: SMALL PARTS, KEEP AWAY FROM CHILDREN.
9. Do not expose light set to standing moisture.
10. DO NOT DISPOSE OF BATTERIES IN FIRE. BATTERIES MAY EXPLODE OR LEAK.

VPN# / NPF : GT90P4A64L00, GT90P3E20L00, GT90P5482L00, GB18P4A64L00, GB18P5482L01

MADE IN CHINA / FABRIQUÉ EN CHINE  
IMPORTED IN CANADA BY HUDSON'S BAY COMPANY / IMPORTÉ AU CANADA PAR LA COMPAGNIE DE LA BAIE D'HUDSON, TORONTO, ON M5H 2Y4  
IMPORTED IN U.S.A. BY / IMPORTÉ AUX ÉTATS-UNIS PAR CREATIVE DESIGN STUDIOS LLC, 225 Liberty Street, New York, NY 10281 · D#2056330

## INSERTION DES PILES

1. Repérer le compartiment à piles.
2. Dévisser le couvercle du compartiment à piles.
3. Insérer 3 piles AA (NON COMPRIS) dans le compartiment à piles en respectant la polarité (fig 1).
4. Revisser le couvercle du compartiment à piles.  
Appuyer sur le bouton MARCHE/ARRÊT pour allumer les lumières.
5. RECYCLER LES PILES USAGÉES SELON LA RÉGLEMENTATION EN VIGUEUR.

## MINUTERIE

Ce boîtier de commande est muni d'une minuterie préprogrammée.

1. Pour l'actionner, appuyer sur le bouton MARCHE/ARRÊT (fig. 2). Les lumières resteront allumées pendant 6 heures, puis s'éteindront automatiquement pour 18 heures.
2. Ce cycle sera maintenu tant que le bouton MARCHE/ARRÊT ne sera pas pressé à nouveau.

## AVERTISSEMENTS

1. Ne pas alimenter ce produit à l'aide d'une combinaison de piles alcalines, standards (carbone-zinc), au lithium ou rechargeables (NiCd, NiMH ou autres).
2. Retirer les piles si elles sont à plat ou si le produit n'est pas utilisé pour une longue période.
3. Disposer des piles usagées de façon appropriée.
4. Nettoyer les bornes des piles avant d'installer ces dernières.
5. Utiliser uniquement des piles AA.
6. Ne pas alimenter ce produit à l'aide d'une combinaison de piles usagées et de piles neuves.
7. Pour usage à l'intérieur et à l'extérieur.
8. AVERTISSEMENT : CE PRODUIT CONTIENT DES PETITES PIÈCES. LE GARDER HORS DE LA PORTÉE DES ENFANTS.
9. Ne pas exposer le jeu de lumières à l'humidité.
10. NE PAS JETER LES PILES DANS LE FEU. CELLES-CI POURRAIENT COULER OU EXPLOSER.