


Twinkly Demo Mode Instructions


* For Store Managers only

1.



1. To activate demo mode, press and hold the controller button for 15 seconds until the LED indicator turns YELLOW.


2.



2. In demo mode, the tree will rotate among 5 different effects. Each effect will play for 30 seconds in the following sequence: Rainbow → Snow → UpDown → Fireworks → Glow. Customers can try out the different light effects/colors via the Twinkly™ app.

NOTE: If the tree is idle for 15 seconds, or if the power is turned off and turned on again, it will resume back to demo mode until it is deactivated.

3.



3. To deactivate demo mode, press and hold the controller button for 15 seconds until the LED indicator turns YELLOW.