

NEED HELP?


DO NOT RETURN TO STORE. PLEASE VISIT US AT:
www.polygroupstore.com OR 1-888-919-0070

Thank you for purchasing your **Smart Tree** from **Polygroup**®! This tree comes with Quick Set® technology - Set up and light up your tree in less than 10 minutes! The instructions below will help you set up your new tree quickly and easily.


ASSEMBLY INSTRUCTIONS

1. Find a flat, level surface near an electrical outlet and assemble the tree stand as shown in **Fig. A**.

Fig. A - Tree Stand Assembly




Pull apart the legs of the stand so that they are snapped into an x-shape, place the tree stand on a level surface.



To close the stand, press the metal button and fold the legs together.

Fig. B - Tree and Light Assembly



***Electrical Rating For The Tree (For Indoor Use Only)**

Input: 120 V~, 60 Hz, 0.25 A
Output: 29 V DC 0.45 A

2. Each tree section is numbered with a sticker. Identify all sections before assembling.

3. Assemble the tree from the bottom to the top (**see Fig. B**). Open the protective cap on the lower pole, then insert the upper pole until firmly secured.

* It's easier to check the pole connectivity and shape the branches, section by section.

4. For pre-lit trees, plug the power cord/adapter into the wall outlet. Tree Section 1 should be lit instantly. If it's not, or some bulbs do not light or flicker, see **TROUBLESHOOTING TIPS** to fix it before moving on to the upper section.

5. For shaping, allow branches to fall into place or gently pull upwards and outwards; make sure that all wires are free of branch hinges. Always start with the lowest tips closest to the pole; pull the individual tips alternately upwards and outwards (**see Fig. C**) and work your way to the tip of the branch. Continue to work row by row until the top row of the section is shaped.

6. Repeat Step 3-5 until the Tree Top is installed. Your tree is now ready to be decorated.

Fig. C




LIGHTS SETUP

Preliminary Steps


Set up your Amazon Echo device and Alexa app. Please follow the instructions of the device. Please use the **same email you used for Echo device** throughout the entire Polygroup Smart Tree setup process.

Add Your Tree into Alexa Skills


1. In the Alexa app, open the "Home" menu.





2. Select "Skills".




3. Search "Polygroup Smart Tree".




Select and press "Enable".



4. Sign in to your Amazon Echo account.




Your tree is now linked to Alexa.




Connect Your Tree to Our APP

1. Download the “Polygroup Smart Products Setup” app from the Apple App Store or Google Play Store.



2. Plug in your tree to the wall outlet. Wait for 5 seconds.




3. In your mobile Settings, turn “Location” on. Then open “Wi-Fi”, select and “Connect” to your tree Wi-Fi “iot_XXXXXX”.




“XXXXXX” is the unique ID of your tree Wi-Fi. If it cannot be detected, press and hold the button of Light Controller for 15 seconds to reset and try again.


4. Open the “Polygroup Smart Products Setup” app.



Select “Network Settings”.




- Select your local Wi-Fi SSID, enter the password and "Confirm" to connect.




- When connecting, the tree lights will display the default effect (Color Change) or the last selected effect. Connection successful: lights flash in multi-colors for 5 times, then in multi-color/white alternating fading. Connection failed: lights flash in white twice before turning off, and repeat

Register Your Tree to Amazon Account


- Now, go to "Home - Settings" and connect back to your local Wi-Fi "XXXXXX".




Open the Polygroup app again. Select "Device Register".











- Enter your Amazon Echo email. The MAC barcode number is auto-filled. Tap "Register".



A dialog box of "Register Completed" will pop up. Tap "OK" to complete.



Once finished, enjoy the tree lights by giving the below voice commands:

Button	Function	Command
	Change lights to White	"Alexa, tell Smart Tree, White."
	Change lights to Fade White	"Alexa, tell Smart Tree, Fade White."
	Change lights to Blink White	"Alexa, tell Smart Tree, Blink White."
	Change lights to Multi-color	"Alexa, tell Smart Tree, Multi-color."
	Change lights to Fade Multi-color	"Alexa, tell Smart Tree, Fade Multi-color."
	Change lights to Blink Multi-color	"Alexa, tell Smart Tree, Blink Multi-color."
	Change lights to Color Change	"Alexa, tell Smart Tree, Color Change."
	Turn OFF the lights	"Alexa, tell Smart Tree, Off."
	Turn ON the lights	"Alexa, tell Smart Tree, On."

You can also change the light effects by pressing the button on the Light Controller (see Fig. B).

HELP MODE

If you don't know what to say to Alexa after setup is completed, you can call HELP to get into Help mode.

The dialogue is listed below:

Alexa: Thank you for choosing Polygroup Smart Tree. I take 9 commands, they are:

1. ON; 2. OFF; 3. Fade White; 4. White; 5. Color Change; 6. Multi-color; 7. Fade Multi-color; 8. Blink White, and 9. Blink Multi-color. What would you like me to do?

ERROR MODE

There may be instances where Alexa doesn't understand your commands.

The dialogue is listed below:

Alexa: I'm not sure I understand. I take 9 commands, they are:

1. ON; 2. OFF; 3. Fade White; 4. White; 5. Color Change; 6. Multi-color; 7. Fade Multi-color; 8. Blink White, and 9. Blink Multi-color. What would you like me to do?

STORAGE INSTRUCTIONS

1. Unplug the product from power.
2. Remove all ornaments and decorations.
3. Disassemble the tree from the top to the bottom. Lift the Tree Top gently straight up to remove from the section below and fold all branches towards the pole. Continue until Section 1 is removed from the stand.
4. Close all the protective caps tightly (see Fig. D).
5. Carefully place all the tree sections into the included tree bag (if any) within the packaging box(es) and tape the box(es) shut.
6. Store the box(es) in a cool, dry place away from direct sunlight. Exposing your tree to excessive heat or humidity may damage your tree.
7. Keep out of reach of pets and children.



CAUTION:

1. To reduce the risk of fire and electric shock:
 - a) Do not install on trees with needles, leaves or branches covering any metal materials,
 - b) Do not mount or support strings in a manner that can cut or damage wire insulation.
2. Use only the adapter supplied with this product. Using a different adapter will damage the lights and may cause fire, or electrical shock hazards.


TROUBLESHOOTING TIPS

1. For pre-lit trees, if the tree does not illuminate

- Check the power cord/adapter/all light string plugs is/are properly and firmly plugged into the wall outlet.
- Gently turn the poles to make sure they are connected in place.

2. For hinged trees, if some branches are loose

- Place the loose branch into the hinge bracket.
- Insert the included hinge pin through the holes of bracket and secure with the included washer (**see Fig. E**).



3. If Alexa cannot be connected

- Turn Alexa off and on.
 - Unplug the power cable and plug it back.
- Check your internet connection
 - Also check router if Alexa's IP address is blocked
- Ensure firmware is updated
 - Press and release mute button, light will turn red.
 - Keep it muted for up to 30 minutes. Firmware will be updated shortly after.
- Reset Alexa to Factory Defaults
 - Press and hold the "microphone off" and "volume down" buttons at the same time until light ring turns orange.
 - Follow instructions Alexa tells you
- Check Amazon Support

4. If Smart Tree cannot connect to Alexa

- Check the internet and wi-fi connection
- Make sure the tree is in range of the wi-fi

5. If Smart Tree is not responsive to the commands or Alexa has trouble understanding

- Refer to help mode
- Refer to error message

SPARE PARTS

This tree includes hinge pins & washers. To order extra parts, please contact our Customer Service Center.

CUSTOMER SERVICE FOR CHRISTMAS TREES

For any questions, assistance, or missing parts, **Do Not Return To Place Of Purchase**. Please contact us at 1-888-919-0070 or visit our website at www.polygroupstore.com. One of our customer service representatives will be happy to assist you.

Tree ID#: _____

Customer Name: _____

Tree UPC#: _____

Address(No P.O. Boxes): _____

Store Purchased: _____

City & State: _____

Specify Problem: _____

Zip Code: _____

Day Phone: _____

Date Purchased: _____

TREE ID# IS LOCATED ON END PANEL OF BOX. TREE ID# IS REQUIRED WHEN REQUESTING REPLACEMENT PARTS.